




MADE IN THE USA

KEYSCO TOOLS
DIVISION OF S&H INDUSTRIES, INC.
5200 Richmond Road • Cleveland, OH 44146
Phone 216-831-0550 • Toll Free 800-253-9726 •
Fax 216-831-9573
www.shindustries.com
E-Mail: www.service@shindustries.com
Rev. 10/7/21

MOBILE ALUMINUM WINDSHIELD RACK – 73740



Tools required for assembly:

7/16" wrench, 7/116" socket and driver

| Part | Qty. | Description |
|-------|------|------------------------------|
| 12262 | 2 | Cross member assembly |
| 12267 | 2 | Vertical support assembly |
| 11532 | 12 | Upright foam padding |
| 10793 | 10 | 1/4" x 1" PSA foam base pads |
| 11381 | 12 | Square end caps |
| 11983 | 4 | 2-1/2" all thread Bolts |
| 10218 | 4 | Washer |
| 10187 | 4 | 1/2-13 Hex nut |
| 12170 | 2 | Swivel caster |
| 12171 | 2 | Swivel caster with lock |

Step 1 – Attach cross members to upright assemblies

Parts required: 2 upright assemblies, 2 cross members, four 2" bolts and 4 washers
Place cross member between the uprights and fasten in place with bolt and washer.

Step 2 – Attach square end caps

Parts required: 12 square end caps
Place square end caps on to the tops of the upright support arms.

Step 3 – Attach upright foam pads

Parts required: 12 upright foam pads
Slide foam covers on to support bars. Remove adhesive strips and bond the cover to itself.

Note: Do not remove strips prior to placing on the support bars. The adhesive bonds quickly.

Step 4 – Attach foam base pads

Parts required: 10 foam base pads
Attach the foam base pads between each of the uprights.

Step 5 – Attach casters to completed windshield rack

Parts required: 2 swivel casters with lock, 2 swivel casters, 4 caster nuts
Attach the swivel casters with caster nuts.